

Slider

by **Carter**
Enterprises

Accuracy Defined Through Design



General Directions for Use:

To Adjust

Loosen both screws $\frac{1}{2}$ turn. You should be able to feel the hook turn freely. Snug the set screw (without the head until you feel it lightly touch the hook. Position the hook to desired angle. Tighten the socket head cap screw. Snug the set screw. **DO NOT OVERTIGHTEN.** You will flatten the point on the set screw and possibly round out the cap screw. Each indentation in the hook is four degrees. Pull test the release on a loop of rope to make sure everything is safe to hold bowstring weight and allow you to gauge the speed.

Thumb Post

Carter Enterprises recommends wrapping your thumb completely around the thumb post, thus insuring the release is at the proper angle when drawing back. Note: if the release is not at the proper angle when drawing back, there is a chance the release will fire prematurely and may cause damage.