

Quickie 1

by **Carter**
Enterprises

Accuracy Defined Through Design



General Directions for Use:

Trigger Travel

To adjust the trigger travel*, turn the set screw clockwise for less travel, and counterclockwise for more travel. After adjusting the set screw, test the release by hooking a string to a stationary object and test-firing the release. Caution: if the set screw is adjusted for insufficient travel, the release may fire prematurely and possibly cause damage.

**Travel refers to the degree the trigger will move prior to the release firing.*

Adjusting Release Length

The length of this release can be adjusted by lengthening or shortening the connecting strap which links the wrist strap to the head of the release. Once you have adjusted the length, loop the strap back through the small buckle to secure its position. *Warning: Failure to double-back through the small buckle on the connector strap could cause the head of the release to come loose during the execution of a shot.*

For more information, contact Carter Enterprises technical support at 1-208-624-3467.