


Like Mike

by **Carter**
Enterprises

Accuracy Defined Through Design



General Directions for Use:

Trigger Travel

To adjust the trigger travel, turn the set screw counterclockwise for more travel and clockwise for less travel. After adjusting the set screw, test the release by hooking a string to a stationary object and pull-test and fire the release to make sure it is safe to hold drawing weight. Caution, if the set screw is adjusted for insufficient travel, the release may fire prematurely and possibly cause damage or injury.

Trigger Tension Adjustment

The Like Mike has a tension adjustment from 0 to 5 pounds. To adjust, move the strap out of the path of the hex key to the adjustment hole and insert the 3/32 hex key. Turn the key clockwise for more tension and counterclockwise for less tension. It is recommended to pull test the release as outlined in the trigger travel instructions.

Strap Adjustment

Loosen the two 3/32 screws on the clamp of the strap and adjust to desired length. Retighten for a solid, no slip fit.