

Evolution 20



Tension Adjustment

Using the supplied .050 hex key, loosen the locking screw located on the back side of the release. Using the supplied 1/16 Hex key, simply screw in clockwise for more holding weight, or out counterclockwise for less holding weight. The tension will range from approximately 10 pounds up to 40 pounds. This will fit the weight ranges of most compound bows. Use minute adjustments for best results. *Caution, always pull test on a simulator before attempting to draw your bow after adjustment to avoid possible misfire and damage.* Once you achieve the desired setting, snug down the locking screw. Use caution to not overtighten the nylon tip screw.

Recommended Use

To close the jaw, push down on the hasp until it snaps into the closed position. Push in and hold the thumb safety while

drawing. **CAUTION! Drawing or letting down your bow without the safety depressed will cause your bow to fire prematurely!**

Once drawn and on target, release the safety and simply pull into the backwall of your bow. When the holding weight meets the weight that the release is set it will activate the firing system, thus firing the release. In order to let down, simply push and hold the safety in again, and let down safely.

For more information, Please contact customer support at 208-624-3467 or email contact@carterenterprises.com