


Revelation

by **Carter**
Enterprises

Accuracy Defined Through Design



Trigger Travel Adjustment:

Trigger travel refers to the amount of movement the trigger will move before the release fires. This is not to be confused with trigger tension. To adjust travel we recommend cocking the Revelation, then screw the travel set screw in (clockwise) until the trigger fires. Back the screw out approximately $\frac{1}{4}$ turn. Cock the release and test fire the release on a simulator before drawing your bow. Insufficient travel adjustment may cause the release to fire prematurely and possibly cause damage or injury.

Trigger Tension Adjustment:

The features the Magnet adjustment tension system. To lighten the tension, simply push out one or two magnets to achieve the desired tension. When magnets are not in use put them in the spare magnet storage holes.

Adjusto Trigger and Bar:

The Revelation release includes an adjustable knurled knob as well as an adjustable bar to help the release fit more comfortably in your hand. To adjust the knurled knob, loosen either bolt, rotate the bar or knob to the desired fit, and re-tighten the bolt to hold the Adjusto Trigger and bar in position.

Recommended Use:

When drawing back, always keep your thumb away from the trigger. Simply hook the Revelation into your d-loop, draw and anchor. Once anchored and on target, apply your thumb to the trigger and gently pull through the shot. This should fire the release in a smooth controlled motion giving you consistent accurate shooting.