

Plain 1

by **Carter**
Enterprises

Accuracy Defined Through Design



Trigger Travel:

To adjust the trigger travel, turn the set screw counterclockwise for more travel and clockwise for less travel. After adjusting the set screw, test the release by hooking a string to a stationary object and pull-test and fire the release to make sure it is safe to hold drawing weight. Caution: if the set screw is adjusted for insufficient travel, the release may fire prematurely and possibly cause damage or injury.

**Travel refers to the degree the trigger will move prior to the release firing.*

Trigger Spring Tension Adjustment:

The Interchangeable Tension System (ITS) allows archers to quickly change from one trigger spring tension to another. To exchange springs, put thumb pressure on the small black box near the thumb trigger and carefully remove the case screw using a 1/16 hex key. Keeping in mind that the spring is adding tension to the black box, slowly remove thumb and box will follow. Once the first spring is removed, fit the desired spring into place, replace box, and hold with thumb while replacing case screw. Remember to pull test the release on a loop of rope or other simulator before attempting to draw your bow.

General Directions for Use:

Simply slip your d-loop into the jaw slot and push in on the cocking lever. This will close your jaw on the loop and lock it. Draw and anchor while keeping your thumb away from the trigger. After anchoring and acquiring your target gently rest your thumb on the trigger. Applying thumb pressure will fire the release.